

## EPL2 – Etiketten

Knochen

Brillenfassung 200dpi

N  
I8,A  
Q78,024  
S3  
JB  
ZB  
D6  
A138,000,0,4,1,1,N,"0000.00E"  
A138,031,0,1,1,1,N,"FABRIK"  
A172,031,0,1,1,1,N,"KOLL"  
A218,031,0,1,1,1,N,"MODELL"  
A138,046,0,1,1,1,N,"FARBEX"  
A188,046,0,1,1,1,N,"XX-XX"  
A248,046,0,1,1,1,N,"EKJ"  
A260,046,0,1,1,1,N,"EKCOD"  
A320,046,0,1,1,1,N,"BARCOD"  
A435,046,0,1,1,1,N,"FK"  
B320,000,0,2,1,3,38,N,"BARCOD"  
P1

Sonnenbrillen 200dpi

N  
I8,A  
Q78,024  
S3  
JB  
ZB  
D6  
A138,000,0,4,1,1,N,"0000.00E"  
A138,031,0,1,1,1,N,"FABRIK"  
A172,031,0,1,1,1,N,"KOLL"  
A218,031,0,1,1,1,N,"MODELL"  
A280,031,0,1,1,1,N,"GT"  
A138,046,0,1,1,1,N,"FARBEX"  
A188,046,0,1,1,1,N,"XX-XX"  
A248,046,0,1,1,1,N,"EKJ"  
A260,046,0,1,1,1,N,"EKCOD"  
A320,046,0,1,1,1,N,"BARCOD"  
A435,046,0,1,1,1,N,"FK"  
B320,000,0,2,1,3,38,N,"BARCOD"  
P1

N  
I8,A  
Q224,036  
S2  
JB  
ZB  
D6  
A220,160,3,4,1,1,N,"0000.00E"  
D5  
A255,160,3,1,1,1,N,"FABRIK"  
A255,120,3,1,1,1,N,"KOLL"  
A255,65,3,1,1,1,N,"MODELL"  
A270,160,3,1,1,1,N,"FARBEX"  
A270,90,3,1,1,1,N,"XX-XX"  
A320,70,1,1,1,1,N,"EKJ"  
A320,15,1,1,1,1,N,"EKCOD"  
A335,15,1,1,1,1,N,"BARCOD"  
D2  
B375,15,1,2,1,3,35,N,"BARCOD"  
P1

oder

N  
I8,A  
Q208,024  
S3  
JB  
ZB  
D8  
A220,165,3,4,1,1,N,"0000.00E"  
A255,165,3,1,1,1,N,"FABRIK"  
A255,125,3,1,1,1,N,"KOLL"  
A255,75,3,1,1,1,N,"MODELL"  
A270,165,3,1,1,1,N,"FARBEX"  
A270,90,3,1,1,1,N,"XX-XX"  
A330,75,1,1,1,1,N,"EKJ"  
A330,20,1,1,1,1,N,"EKCOD"  
A345,20,1,1,1,1,N,"BARCOD"  
B385,20,1,2,1,3,35,N,"BARCOD"  
P1

**300dpi**

N  
I8,A  
oRE,63  
Q322,026  
S1  
JF  
ZB  
D6  
A38,275,3,4,1,1,N,"0000.00E"  
D4  
A90,275,3,1,1,1,N,"FABRIK"  
A90,225,3,1,1,1,N,"KOLL"  
A90,165,3,1,1,1,N,"MODELL"  
A110,275,3,1,1,1,N,"FARBEX"  
A110,190,3,1,1,1,N,"XX-XX"  
A175,70,1,1,1,1,N,"EKJ"  
A175,100,1,1,1,1,N,"EKCOD"  
A200,70,1,1,1,1,N,"BARCOD"  
D1  
B245,70,1,2,2,5,41,N,"BARCOD"  
P1